



Modulay Supporta Pad UL4405

February 20, 2008

Product Description:

GEI Modulay Supporta Pad Underlay (MSP) is a latex rubber sponge underlay designed for Dual Bond Installation. It is produced in a continuous sheet with square trimmed edges and is to be free of holes, imperfections and inclusions.

Adhesion of Modulay Supporta Pad to Subfloor

Prepare floor to specification ensuring concrete is primed with Polymer 6000.

- 1) Before use MSP should be removed from its plastic packaging and fully unrolled for a period of no less than 4 hours.
- 2) If installing MSP under Interface sheet goods the underlay should run at right angles to the floorcovering.
- 3) The action bac downside of the MSP should be firmly bonded to the subfloor with Polymer 999 Acrylic PS adhesive using a 1.6mm x 1.6mm V notched towel.
- 4) The MSP should then be lowered into the adhesive when Tack up is evident and rolled with a roller of no more than 30kgs. All joints to be close fitted and avoid excessive rolling while curing.

Adhesion of Modular carpet tiles

- 1) Apply Polymer 999 PS to the surface of the underlay using a 1.6mm x 1.6mm V notched trowel and allow to dry to manufacturers specs before laying carpet into adhesive.
- 2) Roll completed installation with a roller no larger than 30kgs
- 3) Finishing should be carried out in accordance with AS/NZ 3455.2-1996 and in line with manufactures instructions.

(Note : Interface sheet goods unbacked – contact GEI or Interface NZ for instructions)

(Note2: Excessive moisture in the concrete substrate must be treated with Protectcrete Moisture Fix by GEI prior to the above installation procedures)

Contact GEI 09 4437067 / 03 3797067 / help@giltedge.co.nz