



Wednesday, 19 January 2005

Roberts 35 Fine Patch over embossed Vinyl.

Fine Patch 35 can be used over top of old embossed vinyl (Providing of course it is free of contaminants etc to prohibit bond – sand/disc 60 grit paper best practice.). In order for you to achieve this however you must add to the mix the correct amount of Roberts Super Primer 34 two part primer (also known as Polymer 44 two part primer – same product different branding)

The mix ratio is as follows:

1 part (by volume) Roberts Super Primer 34 part 'A' mixed with 1 part (by volume) Roberts Super Primer 34 part 'B'. mix well. Add to this mixture 2 parts (by volume) Fine Patch 35 powder. Combine well.

Nick Richardson
Gilt Edge Industries

Every Flooring Installation Deserves the **"GILT EDGE"** Finish

Unit 3/7, Colway Place
Glenfield, Auckland
Ph (09) 443 7067
Fax (09) 444 0510

13 Fairfax Avenue
Penrose, Auckland
Ph (09) 579 7067
Fax (09) 579 7064

50 Fitzherbert Street
Petone, Wellington
Ph (04) 569 7067
Fax (04) 569 7066

47 Carlyle Street
Sydenham, Christchurch
Ph (03) 379 7067
Fax (03) 379 2149

15 Turakina Road
South Dunedin
Ph (03) 455 7067
Fax (03) 455 7069

Cnr Wildman Ave
& Vickerman St,
Nelson
Ph (021) 363 484